

DAIHATSU SIRION

Chassis

Service manual

SECTION INDEX

SECTION NAME	SECTION
GENERAL INFORMATION	GI
MAINTENANCE	MA
MANUAL TRANSMISSION	MT
AUTOMATIC TRANSMISSION	AT
TRANSFER	TR
PROPELLER SHAFT	PR
DIFFERENTIAL	DF
REAR AXLE & SUSPENSION	RS
BRAKE (Including A.B.S)	BR
BODY ELECTRICAL	BE
HARNESS & WIRING DIAGRAM	HW

