

DAIHATSU TYPE EJ ENGINE

Service manual

SECTION INDEX

SECTION NAME	SECTION
GENERAL INFORMATION	GI
ENGINE MECHANICAL	EM
EMISSION CONTROL	EC
EFI SYSTEM	EF
LUBRICATION SYSTEM	LU
COOLING SYSTEM	CO
IGNITION SYSTEM	IG
STARTING SYSTEM	ST
CHARGING SYSTEM	CH

